





MA-100 DECK MOUNTED 3-HOLE LAV FAUCET
Spout—Handle Combinations



MA-100 DECK MOUNTED 3-HOLE LAV FAUCET
Exploded Parts Diagram





MA-100 REPLACEMENT PARTS			
DESCRIPTION	PART NUMBER	FINISH REQUIRED	PARTS INCLUDED
PINCH LEVER HANDLE ONLY	MAP-301-HDL	✓	1, 5
OCTAGONAL LEVER HANDLE ONLY	MAL-301-HDL	✓	2, 5
PINCH CROSS HANDLE ONLY	MAC-301-HDL	✓	3, 5
OCTAGONAL CROSS HANDLE ONLY	MAX-301-HDL	✓	4, 5
HANDLE BASE FOR PINCH HANDLES	MAP-301-BASE	✓	6, 8
HANDLE BASE FOR OCTAGONAL HANDLES	MA-301-BASE	✓	7, 8
BROACH EXTENSION SCREW	82G69500-001		9
BROACH EXTENSION	81H39020-001		10
LOCK NUT	LN-DV-05		15,16
1/2" CARTRIDGE, HOT	G065D-H		13
1/2" CARTRIDGE, COLD	G065D-C		14
AERATOR	86M50400-001		19
AERATOR REMOVAL KEY (NOT SHOWN)	A9Z50400-001		-
SPOUT O-RING	88L56500-001		20
SPOUT MOUNTING HARDWARE	A5A00900-001		21
FLEXIBLE HOSE, (1 EACH)	A2D00800-001		22
SET SCREW (M4X3)	89G04900-001		5
1/2" VALVE ASSEMBLY, HOT, COMPLETE	AF-1015-OM-Z-H		11 (13, 15, 16)
1/2" VALVE ASSEMBLY, COLD, COMPLETE	AF-1015-OM-Z-C		12 (14, 15, 16)
PINCH LEVER HANDLE ASSEMBLY, COMPLETE	MAP-301	✓	1, 5, 6, 8, 9, 10
OCTAGONAL LEVER HANDLE ASSEMBLY, COMPLETE	MAL-301	✓	2, 5, 6, 8, 9, 10
PINCH CROSS HANDLE ASSEMBLY, COMPLETE	MAC-301	✓	3, 5, 6, 8, 9, 10
OCTAGONAL CROSS HANDLE ASSEMBLY, COMPLETE	MAX-301	✓	4, 5, 6, 8, 9, 10
MA PINCH LAV SPOUT ASSEMBLY, COMPLETE	MAP-102	✓	17, 19, 20, 21, 22
MA 90° SPOUT ASSEMBLY, COMPLETE	MA-102	✓	18, 19, 20, 21, 22

MA-100 DECK MOUNTED 3-HOLE LAV FAUCET
Mounting Specifications

