



Certified to comply with ASME A112.18.1

© 2016 American Standard

American Standard

NOTE TO INSTALLER: Please give this manual to the customer after installation.

To learn more about American Standard Selectronic® Products visit our website at: www.americanstandard-us.com or e-mail us at: CRTTEAM@americanstandard.com

For Parts, Service, Warranty or other Assistance, please call (844) CRT-TEAM / (844) 278-8326 (In Canada: 1-800-387-0369) (In Toronto Area only: 1-905-306-1093) American Standard

Certified Response Technician

Thank you for selecting American-Standard...the benchmark of fine quality for over 100 years. To ensure that your installation proceeds smoothly-please read these instructions carefully before you begin.


UNPACKING


All American Standard Faucets Are Water Tested At Our Factory. Some Residual Water May Remain In The Faucet During Shipping.

The illustration below shows the fitting and all loose items after they have been removed from the carton. Some items may be packaged partially assembled to other items.

- 1. Installation Instructions
- 2. Spout Assembly
- 3. Mounting Kit
- 4. Control Box
- 5. Supply Hose

- **6. 4" Deck plate** (optional, must be ordered separately)
- **7.8" Deck plate** (optional, must be ordered separately)
- **8. Mixing Valve** (optional, must be ordered separately)
- 9. Control Box Cover Screws





TOOLS REQUIRED; Fig. 2

- 1 Slip Jaw Pliers
- 2 Adjustable Wrench
- 3 Plumbers' Putty or Caulking
- 4 Phillips Screwdriver
- 5 Flat Blade Screwdriver
- 6 Electric Drill & 1/4" Drill Bit
- 7 Tape Measure


INSTALLATION


SPOUT ASSEMBLY INSTALLATION; Fig. 1

CAUTION Turn off hot and cold water supplies before beginning

- 1. Connect the two 27" EXTENSION CABLES (1) to the Faucet Sensor Cables.
- Insert 27" EXTENSION CABLES (1), FLEX HOSE (2) and SPOUT SHANK (3) through center hole of mounting surface.
- 3. Assemble "C" WASHER (4) and LOCKNUT (5) onto SPOUT SHANK (3) from underside of mounting surface.
- 4. Align FAUCET and tighten LOCKNUT (5).

Note: 4" and 8" Deck Plates are available for other installations, see page one for information.





MOUNT CONTROL BOX; Fig. 2

1. Determine location of CONTROL BOX (1). It must be located with-in the 14" (356mm) by 21" (533mm) shaded area shown in **Figure 2** in order for electrical connections from the spout assembly to be made.

NOTE: CONTROL BOX SUPPLY HOSE is 20". Distance between wall supply and CONTROL BOX (1) must be taken into consideration.

2. Remove tape from CONTROL BOX COVER (2) and pull off COVER (2). Hold the CONTROL BOX (1) in desired location and mark the four mounting hole locations as shown.

NOTE: Find plastic bag containing 4 M5X16 screws to be used for securing the CONTROL BOX COVER (1) when installation is complete.

NOTE: For AC installation, make power supply connection before mounting CONTROL BOX (1) to wall.


3. It is recommended that the CONTROL BOX (1) be secured to a wall stud or cross brace within the wall using the SCREWS (3) supplied. If the CONTROL BOX (1) is to be installed on tile or plaster walls, the ANCHORS (4) and SCREWS (3) should be used.

Fig. 2 LAVATORY RIM OR MOUNTING SURFACE 14" (356mm) **ENCLOSURE** MOUNTING HOLES **SUPPLIES** 2-3/4" (71mm) WASTE 20"_ (500mm) 21" 3-3/4" (mm) (76mm) (96mm) MOUNTING HOLES

NOTE: If using Mixing Valve (optional) See Sheet #M968808 for installation instructions.

3 CONNECT SPOUT HOSE TO CONTROL BOX; Fig. 3

1. Connect SUPPLY NUT (1) from spout hose to nipple on top of CONTROL BOX (2). Tighten with adjustable wrench to make a water tight connection. Fig. 3.




4 CONNECT WATER SUPPLY TO CONTROL BOX AND WALL SUPPLY; Fig. 4, 4a

NOTE; If using the optional Mixing Valve See Sheet #M968808 for installation instructions.

- 1. Insert FIBER WASHER (4) into SUPPLY NUT (1) on CONTROL BOX (2).
- Connect FLEXIBLE SUPPLY HOSE (3) to SUPPLY NUT (1) on CONTROL BOX (2). Tighten to make a water tight connection. Use two wrenches to tighten if necessary. Fig. 4.
- 3. Connect FLEXIBLE SUPPLY HOSE (3) directly to wall supply. Connection on FLEXIBLE SUPPLY HOSE (3) is 3/8" compression. Use adjustable wrench to tighten connection. Do not over tighten. Fig. 4a.

Note: FLEXIBLE SUPPLY HOSE (3) measures 20" from the bottom of the CONTROL BOX (2) base. If additional supply length is required, installer must purchase parts separately.

Important: If FLEXIBLE SUPPLY HOSE **(3)** is too long, loop to avoid kinking.



ELECTRICAL INSTALLATION

Product	Page
Plug-in AC Power Kit (PK00.PAC)	5
Hard-Wired AC Power Kit (PK00.HAC)	5
MULTI-AC Power Kit (PK00.MAC)	6


☐ DC VERSIONS (PWRX & STANDARD BATTERY); Fig. 1

- 1. Remove CONTROL BOX COVER (1). Fig. 1.
- 2. Feed the 27" EXTENSION CABLES (2) through the top of CONTROL BOX (3). Fig. 1a.

FOR STANDARD BATTERY VERSION ONLY

- 3. Insert BATTERY (4) into BATTERY HOLDER (5), make sure the shape of the BATTERY (4) follows the shape of the BATTERY HOLDER (5) and terminal end is inserted first. Fig. 1b.
- 4. Insert the BATTERY CONNECTOR (5a) from the Standard Battery or PWRX Battery Pack through side GROMMET (6) as shown. Fig. 1c.
- Connect SOLENOID CABLE (7) and BATTERY CONNECTOR (5a) to 27" EXTENSION CABLES (2). Place Standard Battery or PWRX Battery Pack into housing. Fig. 1d.
- **6.** Replace CONTROL BOX COVER **(1)**. Tighten cover screws firmly.

CAUTION: Use only American Standard supplied cable sets. Using non-AS supplied cables, or cutting, splicing or modifying any components will void the warranty.



B ACVERSIONS (HARDWIRE / PLUG-IN); Fig. 2

CAUTION Disconnect AC power supply before opening CONTROL BOX.

NOTE: For AC installation, make power supply connection before mounting CONTROL BOX (3) to wall.

 Remove CONTROL BOX COVER (1). Feed the EXTENSION CABLES (2) from the Faucet through the top of CONTROL BOX (3). Install CONNECTOR LOCKING DEVICE (16). Fig. 2.

FOR PLUG-IN HOOKUP ONLY

- 2a. Insert POWER CORD (8) through POWER SUPPLY GROMMET (9) Fig. 2a.
- **3a.** Insert POWER CORD **(8)** through side GROMMET **(6)** as shown. **Fig. 2a.**
- **4a.** Connect 27" EXTENSION CABLES **(2)** to SOLENOID CABLE **(7)** and POWER CORD **(8)**. Connect it to the SINGLE AC ADAPTER **(10)**. **Fig. 2a.**
- **5a.** Mount CONTROL BOX to wall. Replace CONTROL BOX COVER **(1).** Tighten cover screws firmly.
- 6a. Plug AC POWER SUPPLY into wall outlet.


FOR HARDWIRE HOOK-UP ONLY;


- **2b.** Insert one end of the 10' EXTENSION (10a) through POWER SUPPLY GROMMET (9). Fig. 2b.
- **3b.** Insert 10' EXTENSION (10a) through side GROMMET (6) as shown. Fig. 2b.
- **4b.** Connect 10' EXTENSION (10a) to single terminal of SINGLE AC ADAPTER (11). Fig. 2b.
- 5b. Connect 27" EXTENSION CABLES (2) to SOLENOID CABLE (7) and to the terminal at the one end of the SINGLE AC ADAPTER (11).
- **6b.** Mount CONTROL BOX **(3)** to wall. Replace CONTROL BOX COVER **(1).** Tighten cover screws firmly.

Contractor to supply ELECTRICAL BOX (12) and power to POWER SUPPLY (13).

- **7b.** Mount POWER SUPPLY (13) into ELECTRICAL BOX (12). Connect White and Black connections to POWER SUPPLY CONNECTIONS (14). Fig. 2c.
- **8b.** Connect the 10' EXTENSION (10b) to the POWER SUPPLY CABLE (15). Fig. 2c.

CAUTION: Use only American Standard supplied cable sets. Using non-AS supplied cables, or cutting, splicing or modifying any components will void the warranty.





MULTI-AC VERSION (DAISY-CHAIN); Fig. 3, 3a


Important: All control box covers must be removed before beginning to make daisy-chain connections.

Disconnect the first unit's Y-Adapter from power supply before making daisy-chain connections.

Note: For Unit #1 electrical instructions, refer to section B (page 5). For subsequent Units, refer to instructions below...

- 1. Remove COVERS from all CONTROL BOX (3).
- 2. Insert pervious unit's 10' EXTENSION (11a) through gray GROMMET (5b) and connect to single terminal of Y-ADAPTER (11).
- Remove solid black plug grommet from left side of all CONTROL BOX (3), and replace with GRAY GROMMET (5b). (Supplied with each Faucet).
- 4. Feed 27" EXTENSION CABLES (2) through the top of CONTROL BOX (3). Connect one 27" EXTENSION CABLE (2) to the SOLENOID CABLE (7), and the other to either of the two terminals at the one end of the Y-ADAPTER (11). Connect the current unit's 10' EXTENSION (10a) to available terminal of the Y-ADAPTER (11).
- Feed the other end of the 10 ft.EXTENSION (10b)
 through the two GRAY GROMMETS (6a and 6b) and
 connect to the single terminal of the next unit's
 Y-ADAPTER (11). Place Y-ADAPTER (11) into
 CONTROL BOX (3).
- **6.** Repeat Steps above for each additional **Unit**, for a **Max. of 15 Units** on one AC POWER SUPPLY.
- **7.** Replace CONTROL BOX COVERS. Tighten cover screws firmly.

CAUTION: Use only American Standard supplied cable sets. Using non-AS supplied cables, or cutting, splicing or modifying any components will void the warranty.



M965653 Rev. 1.6 (11/16)

MAINTENANCE

A HAND WASH SENSOR OPERATION; Fig. 1


When the Sensor detects a user, the water immediately starts to flow. Water flow will stop 2 seconds after user is out of sensor range. The off delay allows the user to comfortably move his hands without the flow cycling on and off. As a precaution, a safety timer will turn off the water, after the sensor has been blocked for 59 seconds. The water will stay off until the blockage is removed from the detection zone.

Detection Zone: 2" - 10" (50mm - 250mm) Default: Set at Factory 6" (150mm)

E CHANGE SENSOR RANGE; (Factory set at 6") Fig. 2, 2a

- **1.** Remove cover from CONTROL BOX. Disconnect Power Supply **(1)**, then reconnect. **Fig. 2.**
- 2. While the SENSOR CONTROL LED (2) is blinking slowly, place your hand 1 2 in. (30-50mm) in front of the sensor. Fig. 2a.
- **3.** When the LED stops blinking and stays "ON", move your hand to the desired position and hold in place until the LED begins to blink again. **Fig. 2a.**
- 4. Once the SENSOR CONTROL LED (2) begins to blink again, remove your hand from the detection zone. When the flashing stops, the detection distance is set.
- **5.** Replace CONTROL BOX COVERS **(2)**. Tighten cover screws firmly.

Fig. 1 DETECTION ZONE



© CLEAN FILTER ASSEMBLY; Fig. 3

CAUTION Before opening CONTROL BOX disconnect AC power supply.


- 1. Remove CONTROL BOX COVER.
- 2. Close SUPPLY STOP (13) with 4mm Hex wrench.

Note: Activate sensor to keep water flowing out of faucet while shutting off.

- 3. Unthread FILTER ASSEMBLY (6) using a 7/16" socket.
- **4.** Pull out the FILTER ASSEMBLY **(6)**, remove and clean white debris cup and filter screen.
- 5. Install the FILTER ASSEMBLY (6) back in its place and tighten with a 7/16" socket.

Caution: Do not over tighten.

- 6. Open SUPPLY STOP (13) with 4mm Hex wrench.
- **7.** Replace CONTROL BOX COVER. Tighten cover screws firmly.



D INSTALL/REPLACE THE BATTERY or PWRX; Fig. 4

- 1. Remove COVER from CONTROL BOX (1).
- Disconnect BATTERY HOLDER (3) from 27" EXTENSION CABLE (5).
- 3. Remove old BATTERY from BATTERY HOLDER (3). Install new BATTERY (2) making sure the terminal side is inserted first and shape of the battery follows the shape of the BATTERY HOLDER (3).
- **4.** To replace PWRX BATTERY PACK **(4)**, unplug and replace with new Power Pack.
- 5. Reconnect BATTERY HOLDER (3) to 27" EXTENSION CABLE (5).
- Replace CONTROL BOX COVER. Tighten cover screws firmly.

I CLEAN AND REMOVE THE AERATOR; Fig. 5


- Remove AERATOR HOUSING (1) with KEY supplied with faucet.
- 3. Remove AERATOR (2) from HOUSING (1).
- 2. Clean the AERATOR SCREENS (3).
- **4.** Clean with water. Reassemble and install into spout end. Make sure black seal washer is in place.


GENERAL CLEANING; Fig. 6

- **1.** For general cleaning use a damp, soft cloth to clean the spout and the sensor.
- 2. For cleaning dirt use a soft cloth with diluted dish washing detergent. Wipe the area using a wet cloth and dry using a soft cloth.

CAUTION Do not scratch the sensor when cleaning.

Avoid using anything that may scratch the spout surface. Never use polishing power, detergent or a nylon scrub brush. They will damage the surface of the spout or Sensor.








FAQ'S


- **Q:** How will I know if the battery needs to be replaced?
- A: Valve will not open and sensor will continuously blink 2 times interrupted by a pause for up to 7 days.
- Q: Why has the flow rate of the faucet reduced significantly?
- **A:** The filter assembly, flow regulator or areator/spray may be clogged. Check and clean. Refer to Start-up/Maintenance, sections C, D and E.
- Q: Why doesn't the water flow out of faucet when I'm within the sensor detection zone?
- **A:** Battery may need replacement. Check. If sensor continuously blinks 2 times interrupted by pause, replace battery or call (844) CRT-TEAM / (844) 278-8326.
- **Q:** What is the normal operating pressure range?
- A: Faucet will operate with supply pressures ranging from 20-80 psi.

TROUBLESHOOTING FLOW CHARTS


UNIT DOES NOT FUNCTION



WATER IS CONTINUOUSLY RUNNING



LOW FLOW ISSUES



LOW FLOW COULD BE CAUSED BY DEBRIS IN THE FILTER ASSEMBLY, FLOW REGULATOR OR AERATOR/SPRAY. REMOVE, CLEAN AND INSERT BACK TO ORIGINAL POSITION.



IN MEXICO 01-800-839-1200 IN CANADA 1-800-387-0369 (TORONTO 1-905-306-1093)

Weekdays 8:00 a.m. to 7:00 p.m. EST

Product names listed herein are trademarks of AS America, Inc. @2016

To learn more about American Standard Selectronic® Products visit our website at: www.americanstandard-us.com or e-mail us at: CRTTEAM@americanstandard.com

American Standard M922887-YYY0A 1.5 GPM AERATOR 066508-YYY0A 0.5 GPM AERATOR M964904-0070A SENSOR KIT A923672-0070A **FAUCET SUPPLY** HOSE M962411-0070A MOUNTING KIT 605P400.XXX 4" DECK PLATE 605P800.XXX 8" DECK PLATE 044912-0070A M950510-0070A MOUNTING NUT 27" EXTENSION CABLE M964940-0070A CONTROL BOX ASSEMBLY (POWER SUPPLY NOT INCLUDED AND MUST BE ORDERED SEPARATELY) A913202-0070A WASHER A924162-0070A SUPPLY HOSE (H) M964410-0070A SOLENOID ASSEMBLY A950507-0070A FILTER ASSEMBLY A950509-0070A

SUPPLY STOP

PART OF LIXIL

SELECTRONIC® Moments Lavatory Proximity Faucet


MODEL NUMBERS

2506.14X 2506.115X 250B.10X

Appropriate finish code

CHROME

002





HOT LINE FOR HELP

For toll-free information and answers to your questions, call:

(844) CRT-TEAM / (844) 278-8326

Mon. - Fri. 8:00 a.m. to 8:00 p.m. EST Saturday 10:00 a.m. to 4:00 p.m. EST IN MEXICO 01-800-839-1200

IN CANADA 1-800-387-0369 (TORONTO 1-905-306-1093)
Weekdays 8:00 a.m. to 7:00 p.m. EST

Product names listed herein are trademarks of AS America, Inc. @2016

To learn more about American Standard Selectronic® Products visit our website at: www.americanstandard-us.com or e-mail us at: CRTTEAM@americanstandard.com